

Installation Guide for Pre-fabricated Walls with Pryda Bracing



Copyright: (c) Pryda Australia- A Division of ITW Australia March 2012

March 2012



PRYDA TIMBER CONNECTORS Installation Guide For Prefabricated Walls With Pryda Bracing

Copyright: © Pryda Australia- A Division of ITW Australia - ABN 630 0423 5063 - March 2012

INTRODUCTION

This guide applies to the installation of prefabricated wall frames including Pryda bracing products into conventional, timber-framed, residential buildings of one or two storeys complying with **AS1684-2010 Residential timber-framed construction- Part 2 or 3**. These wall frames have been fully prefabricated, including installation of wind bracing units (aka "bracing panels" or "bracing walls"). AS1684 limitations are:

Storeys	One or two
Maximum length in direction of wind, excluding eaves	16000 mm
Maximum wall height	3000 mm
Maximum roof pitch	35 degrees
Wind classification (aka "wind zone")	N1, N2, N3, N4, C1, C2, C3

For builders and wall frame installers, this guide provides details of practical methods of fixing the wall frames to the floor structure and, for internal walls, to the roof.

Other fixing details for these purposes are included in AS1684 Part 2 and Part 3, Tables 8.22 and 8.24.

For simplicity, bracing units in this guide are denoted as "Type A" and "Type B". Design capacities of these units, in kN/m, are specified on the diagrams. Tie-down and shear capacities for connections are also specified in this guide.

PRYDA TIMBER CONNECTORS

Installation Guide For Prefabricated Walls With Pryda Bracing

Copyright: © Pryda Australia- A Division of ITW Australia - ABN 630 0423 5063 - March 2012

(A) TYPE A BRACING UNITS

A1 Bracing Unit Options



Note: Pryda Maxi Brace can be used instead of Mini Brace.

A2 Fixing to floor at bottom plate

Nominal fixing is required, ie:

Floor Type	Fixing Required
Timber	Plate thickness up to:
	38 mm - 2/75x3.05 mm nails @ 600 mm maximum
	50 mm – 2/90x3.05 mm nails @ 600 mm maximum
Concrete slab	One 75 mm masonry nail (hand-driven at slab edge), screw or bolt at 1200 mm centres maximum

A3 Fixing to roof structure at top plate (for non-load bearing walls only)

At all bracing units in internal, non-loadbearing walls, the bracing unit must be connected to the roof as shown below to be effective as part of the bracing system. One connection per each Type A bracing unit is required and it can be located anywhere within the length of the bracing unit.



(a) Trusses Perpendicular to wall



(b) Trusses Parallel to wall

Pryda Shear Connector (PSC) in application (always used in pairs)

BRACING TYPE	Wall Lengths (mm)	No. of pairs of Pryda Shear Connectors	No. of nail fixing onto top plate per connector**
TO A	1800	1	4
	2400	1	4
1.5 kN/m	2700	1	5

Note: Other types of joints for this use are shown in Table 8.22 of AS1684:2010 Parts 2 and 3. In this instance, the connection must allow vertical movement of roof trusses and must have a clearance of at least 10 mm between the truss bottom chord or ceiling battens (if used) and the top plate to allow for truss settlement over time. PRYDA TIMBER CONNECTORS

Installation Guide For Prefabricated Walls With Pryda Bracing

Copyright: © Pryda Australia- A Division of ITW Australia – ABN 630 0423 5063 – March 2012

(B) TYPE B BRACING UNITS

B1 Bracing Unit Option



B2 Fixing to floor at bottom plate

Nominal fixing is required, ie:

Floor Type	Fixing Required	
Timber	Plate thickness up to:	
	38 mm - 2/75x3.05 mm nails @ 600 mm maximum	
	50 mm – 2/90x3.05 mm nails @ 600 mm maximum	
Concrete slab	One 75 mm masonry nail (hand-driven at slab edge), screw or bolt at 1200 mm centres maximum	

Note: Table 8.18 of AS1684.2:2010 nominates that bracing systems with a racking capacity of 3.4 kN/m only require nominal fixing of the bottom plate to the concrete slab. This reduced requirement has been established from whole house testing programs, along with post-wind damage assessments of the performance of bracing in housing.

B3 Fixing to roof structure at top plate (for non-load bearing walls only)

At all bracing units in internal, non-loadbearing walls, the bracing unit must be connected to the roof to be effective as part of the bracing system. The connection can be located anywhere within the length of the bracing unit.

B3A Two Connections Per Unit System- using two pairs of Pryda Shear Connectors





BRACING TYPE	Wall Lengths (mm)	No. of pairs of Pryda Shear Connectors	No. of nail fixing onto top plate per connector**
A A	1800	2	4
	2400	2	4
3.0 kN/m	2700	2	5

Note: Other types of joints for this use are shown in Table 8.22 of AS1684:2010 Parts 2 and 3. In this instance, the connection must allow vertical movement of roof trusses and must have a clearance of at least 10 mm between the truss bottom chord or ceiling battens (if used) and the top plate to allow for truss settlement over time.



PRYDA TIMBER CONNECTORS

Installation Guide For Prefabricated Walls With Pryda Bracing

Copyright: © Pryda Australia- A Division of ITW Australia – ABN 630 0423 5063 – March 2012

B3B Two Connections Per Unit System – using blocks as per AS 1684

Adopt similar details_as shown for Type A units, but provide two connections per Type B bracing unit as shown below. The total Shear Capacity per unit = 8.1 kN



B3C Single Connection Per Unit System



Shear Capacity of these units is 8.1 kN.

Refer Table 8.22 of AS1684:2010 Parts 2 and 3 for alternatives connections.

Pryda Australia | A Division of ITW Australia Pty Ltd 2 - 10 Nina Link, Dandenong South, Vic 3175 Offices in Melbourne, Sydney, Brisbane and Perth. Representatives in all States.

Website: www.pryda.com.au Email: pryda@pryda.com.au Tel: (03) 9554 7001 Fax: (03) 9554 7000